

| Inverters | | |
|-----------|------------------------|----------------|
| Make | Model | AS4777 Version |
| APS | YC500 | 2005 |
| Conext | RL 3000 E | 2005 |
| Conext | RL 4000 E | 2005 |
| Conext | RL 5000 E | 2005 |
| Delta | RPI-H3 | 2005 |
| Delta | RPI-H5A | 2005 |
| Delta | RPI-M6A | 2005 |
| Delta | Solivia 3.3kW AP G3 TR | 2005 |
| Delta | Solivia 2.5kW AP G3 | 2005 |
| Delta | Solivia 3.0kW TR | 2005 |
| Delta | Solivia 3.0kW GT | 2005 |
| Delta | Solivia 5.0kW TR | 2005 |
| Delta | Solivia 5.0kW GT | 2005 |
| Enasolar | 3.8kW GT AU NZ | 2005 |
| Enasolar | 1.5kW GT AU NZ | 2005 |
| Enasolar | 3.0kW GT AU NZ | 2005 |
| Enasolar | 5.0kW GT AU NZ | 2005 |
| Enasolar | 4.0kW GT AU NZ | 2005 |
| Enasolar | 2.0kW GT AU NZ | 2005 |
| Enphase | M215-60-230-S22 | 2005 |
| Enphase | M250-60-230-S22 | 2005 |
| Enphase | S230-60-LN | 2015 |
| Enphase | S270-72-LN | 2015 |
| Fronius | Galvo 1.5-1 | 2005 |
| Fronius | Galvo 2.0-1 | 2005 |
| Fronius | Galvo 2.5-1 | 2005 |
| Fronius | Galvo 3.0-1 | 2005 |
| Fronius | Primo 3.0-1 | 2005 |
| Fronius | Primo 3.5-1 | 2005 |
| Fronius | Primo 3.6-1 | 2005 |
| Fronius | Primo 4.0-1 | 2005 |
| Fronius | Primo 4.6-1 | 2005 |
| Fronius | Primo 5.0-1 | 2005 |
| Fronius | Primo 6.0-1 | 2005 |
| Fronius | Primo 8.2-1 | 2005 |
| Fronius | SYMO 3.0-3-S | 2005 |
| Fronius | SYMO Hybrid 3.0-3-S | 2005 |
| Fronius | SYMO 3.0-3-M | 2005 |
| Fronius | SYMO 3.7-3-S | 2005 |
| Fronius | SYMO 3.7-3-M | 2005 |
| Fronius | SYMO Hybrid 4.0-3-S | 2005 |
| Fronius | SYMO 4.5-3-S | 2005 |
| Fronius | SYMO 4.5-3-M | 2005 |
| Fronius | SYMO Hybrid 5.0-3-S | 2005 |

| | | |
|----------------------------|-----------------------------------|------|
| Fronius | SYMO 5.0-3-M | 2005 |
| Fronius | SYMO 5.5-3-M | 2005 |
| Fronius | SYMO 6.0-3-M | 2005 |
| Fronius | SYMO 6.7-3-M | 2005 |
| Fronius | SYMO 7.0-3-M | 2005 |
| Fronius | SYMO 8.0-3-M | 2005 |
| Fronius | SYMO 8.2-3-M | 2005 |
| Fronius | SYMO 10.0-3-M | 2005 |
| Fronius | IG 40 | 2005 |
| Fronius | IG PLUS 55 V2 | 2005 |
| Goodwe | GW4200DS | 2005 |
| Goodwe | GW4000SS | 2005 |
| Goodwe | GW3000SS | 2005 |
| Goodwe | GW2000SS | 2005 |
| Goodwe | GW5000DS | 2005 |
| Meikai | MKPV-N300-72-AU-02 | 2005 |
| Meikai | MKSKY 5000TLD | 2005 |
| MKSKY | 5000TL SD | 2005 |
| MKSKY | 3300TL | 2005 |
| Meikai MKSTAR | N300 micro inverter | 2005 |
| Panasonic | LJ-SK84A (storage battery system) | 2005 |
| Pantheon 2 | P250LV-230-LV | 2005 |
| PowerOne BenQ | 0.3-I-OUTD-230 | 2005 |
| PowerRouter | CD05A0017 | 2005 |
| PowerRouter Solar Inverter | PR50S | 2005 |
| Renasolar | MicroReplus 250 microinverter | 2005 |
| Samil Power | Solar River 5200TL | 2005 |
| Poweroak | PS63530B/ESS6530 Waru | 2005 |
| | | |
| SMA | Sunny Mini Central 7000 TL | 2005 |
| SMA | Windyboy 3800 | 2005 |
| SMA | Sunnyboy 2100 TL | 2005 |
| SMA | Sunnyboy SB2.5-1 VL-40 | |
| SMA | Sunnyboy 3000 TL | 2005 |
| SMA | Sunnyboy SB3000 HF | 2005 |
| SMA | Sunnyboy SB4000 TL | 2005 |
| SMA | Sunnyboy SB5000 TL | 2005 |
| | | |
| | | |
| SMA | Sunny TriPower 6000 TL | 2005 |
| SMA | Sunny TriPower 9000 TL | 2005 |
| SMA | Sunny Tripower 10000 TL | 2005 |
| SMA | Sunny Tripower 17000 TL | 2005 |
| SMA | Sunny TriPower 20000 TL EE-10 | 2005 |
| SoFarSolar | 3000 TLM | 2015 |
| SoFarSolar | SoFar 3000 TL | 2005 |

| | | |
|-------------|------------------|------|
| Solar Edge | SE2200 | 2005 |
| Solar Edge | SE3000 | 2005 |
| Solar Edge | SE4000 | 2005 |
| Solar Edge | SE5000 | 2005 |
| Solar Edge | SE6000 | 2005 |
| Solar River | 4000TL/SR4K4TLA1 | 2005 |
| Solax | SL-SU 3000E | 2005 |
| Solax | SL-SU 5000 | 2005 |
| Solax | SL-TL 2200 | |
| Solax | SL-TL 4400T | |
| Solax | SK-TL 5000T | |
| Solax | SK-TL 5000E | |
| Sungrow | SG2K5TL-S | 2005 |
| Sungrow | SG3KTL-S | 2005 |
| Sungrow | SG3K5TL-S | 2005 |
| Sungrow | SG4KTL-S | 2005 |